

# Product Brief | Rimage Producer™ IV Series

## Unrivalled Performance, Versatility and Quality

Rimage Producer IV disc publishing systems are the industry standard for anyone producing professional CD, DVD and Blu-ray Discs™. With industrial grade robotics, direct-to-disc printing and professional recording technologies, the Producer IV Series meets the world's most challenging disc production demands.

## Benefits

### Powerful printing

Producer IV systems have the world's best full-color and thermal monochrome disc printers, providing top of the line printing and industrial-grade production in one scalable package.

### Quick turnaround

Designed for 24/7, high-volume, unattended production, Producer IV systems publish hundreds of customizable discs per day, so you can deliver customer-tailored discs faster.

### Superior performance

The four-bin carousel and 100-disc external output bin comes standard with the Rimage system, enabling four media types to be available concurrently. The reliable Rimage robotics are designed to output discs continuously for years.

## Features

- Integrated DiscWatch™ status light
- 100-disc external output bin
- Front USB port
- Internal lighting
- Up to four quick-release front-swappable recorders
- 400-disc rotating carousel for input/output
- Four line LCD status display
- Embedded control center with network connectivity
- Rimage Software Suite (RSS) - Network
- Everest™ 600 printer or Prism III™ printer
  - Everest: Best quality printer for permanent, full-color printing
  - Prism III: Fastest and lowest-cost per disc thermal monochrome printer on the market



Producer 8200N

Producer 7200N

Producer 6200N

## Options

- Blu-ray Recorders
- Everest 600 or Prism III print technology
- DiscFlow™ for Mac
- Media Reader
- Windows Server 2008 R2 Standard

# Product Brief | Rimage Producer™ IV Series

## System Specifications

	Producer 8200N	Producer 7200N	Producer 6200N
<b>Number of Recorders</b>	4	2	1
<b>Carousel / Total Capacity</b>	4 bins / 400 discs	4 bins / 400 discs	4 bins / 400 discs
<b>External Output Bin Capacity</b>	100 discs	100 discs	100 discs
<b>Printer</b>	Everest 600 or Prism III	Everest 600 or Prism III	Everest 600 or Prism III
<b>CPU</b>	Intel Core i5	Intel Core i5	Intel Core i5
<b>HDD Storage</b>	4 x 500 GB RAID 5 / RAID 0	4 x 500 GB RAID 5 / RAID 0	3 x 500 GB RAID 5 / RAID 0
<b>RAM</b>	8 GB	8 GB	8 GB
<b>Operating Systems</b>	Win 7 Ultimate 64-bit (standard), Win Server 2008 R2 Standard (optional)		
<b>Network Capabilities</b>	Yes	Yes	Yes
<b>Rimage Software Suite (RSS) - Network</b>	A full set of software tools enabling unique artwork design, job submission, control center operation, production monitoring and custom application creation.		
<b>CD Designer™</b>	Included	Included	Included
<b>QuickDisc™</b>	Included	Included	Included
<b>DiscFlow™</b>	Optional	Optional	Optional
<b>Web RSM/Rimage System Manager (RSM)</b>	Included	Included	Included
<b>Height</b>	33.5 in / 85.1 cm	30.5 in / 77.5 cm	28 in / 71.1 cm
<b>Width</b>	17.25 in / 43.8 cm	17.25 in / 43.8 cm	17.25 in / 43.8 cm
<b>Depth*</b>	24 in / 61 cm	24 in / 61 cm	24 in / 61 cm
<b>Weight w/ Everest 600</b>	159.5 lb / 72.3 kg	147.5 lb / 67 kg	143.5 lb / 65.1 kg
<b>Weight w/ Prism III</b>	134.5 lb / 61 kg	122.5 lb / 55.6 kg	118.5 lb / 53.8 kg
<b>Power Specifications</b>	100 - 240VAC, 60/50 Hz, 4.7 - 3.7Amp, 500 watt maximum	100 - 240VAC, 60/50 Hz, 4.7 - 3.7Amp, 500 watt maximum	100 - 240VAC, 60/50 Hz, 4.7 - 3.7Amp, 500 watt maximum
<b>Warranty</b>	12 months	12 months	12 months

\* Allow space (3.5" or 9 cm) in rear of machine for cabling.

## We Recommend

### Rimage Maintenance Agreements

Maximize your ROI and minimize downtime when quick problem resolution is a must. With our range of skilled technicians and industry-leading support services, Rimage has a maintenance plan that meets your needs.

### Rimage Media Kits

Get reliable, uninterrupted performance from your Producer IV system. With optimized print ribbons and discs, Media Kits give you the best-looking, longest-lasting results in one convenient and affordable package.

For complete information about Rimage Producer IV Series support options and Media Kits, visit [www.rimage.com/products/producer-series](http://www.rimage.com/products/producer-series).

Distributed By

**HARBTEK**  
SYSTEMS

Beirut, Lebanon  
Tel/Fax: +961 9-477994  
[www.harb-tek.com](http://www.harb-tek.com)

Blu-ray Disc™ is a trademark of the Blu-ray Disc Association.